

PortaScope®

1800PVS4 Operation manual

1. Indicator light

When TF card is not inserted, the indicator light will flash 3 times when power on;

When TF card is inserted, the indicator light will flash once;
Press the photo button, the indicator light will flash once.

2. Power Switch

Press to switch on and press again to power off.

3. TF card slot

Insert the card into slot with chip face down. To take out the card, press the card and it will pop up.

4. Photo button

Press the button once it will take 3 photos and save automatically.

5. Charge interface

The indicator turns to red when charging; It turns to green when full charged.

Please don't power on during it is charging.



Borescopes.us.com
6220 Manatee Ave West Suite 302
Bradenton, FL. 34209
1800.363.6726
+941.792.7138
Fax +941.761.4613

